



DIAMOND

EVENT & TENT

TIP

- Place the system speakers in front of the person speaking to avoid feedback squelches.

| | |
|-----------------|---|
| Supplies Needed | 1 |
| Options | 2 |
| Requirements | 3 |
| Operation | 4 |
| Strike Down | 5 |
| Capacity | 6 |
| Tips | 7 |

FENDER 2-SPKR PLUG-IN KIT

Volume # 2015-A
Document Property of
Diamond Event & Tent ©

SUPPLIES (13)

- Center Amplifier w/controls.
- Attached Left Speaker
- Attached Right Speaker
- Speaker Stands (2)
- Speaker Stands Bag
- Power Cord
- Handheld Microphone
- Mic Cable - 20'
- Mic Transport Bag
- 16' Speaker Cables (2)
- MP3 Player Cable



Sample Photo / Actual Sound System Style May Vary.

OPTIONS

- Heavy Duty Extension Cord - 50' or Less
- NO Wireless Mics are available for this unit.

REQUIREMENTS

- 120 Volt / 5 Amp Power Source

LOCATIONS

SALT LAKE CITY
4518 South 500 West
801-262-2080

OREM
1350 Sandhill Road
801-222-9311

OGDEN
1639 South 1900 West
801-393-5353

OPERATION INSTRUCTIONS

1. Flip open the cabinet latches on the sides and detach speakers.
2. Separate speakers and install on stands.
3. Open storage compartment door and remove 4-cables.
4. Plug speaker cables into the front of each speaker.
5. Plug each speaker cable into the back of the amp unit.
6. Plug left & right speaker cables into their speakers.
7. Make sure the power switch on the back of the amp is turned off.
8. Plug the power cord into the cord socket on the back of unit.
9. Plug the power cord into a power outlet.
10. Plug the microphone cable into 1 of the 3 mono mic plugs.
11. Rotate the MASTER VOLUME knob and all other CHANNEL VOLUME knobs to the left.
12. Turn on any external equipment first.
13. Then turn on the Pass-port system (Green LED Light should illuminate.)
14. Turn the MASTER VOLUME up to 1/4.
15. Adjust CHANNEL VOLUME knobs until their LED light is Green or Yellow. (NOT RED!)
16. If still RED, push the PAD button to reduce the mic/item's volume by 20 decibels.
17. Use the Master Volume control to adjust the overall volume.
18. Adjust the TONE knob to the center. Listen and adjust as needed.
19. Basic set-up in complete!

SPEAKER STANDS

1. Release the larger / lower swivel clamps.
2. Spread three legs in the desired position and lock clamps.
3. Release upper / small swivel clamps.
4. Lift center mast pole to the desired height.
5. Lock the upper / small swivel clamps.
6. Insert the safety locking pin into the mast.
7. Set a speaker atop each speaker stand.
8. Reverse to take down.

CAPACITY

- 3 Handheld Mics
- 250-375 People Inside
- 125-250 People Outside (Actual performance will vary by conditions.)

STRIKE DOWN

- Turn power off
- Unplug system
- Detach Speakers
- Wrap up cables
- Mic w/Cord in bag
- Speaker Stands in large transport bag.