

ICE SHAVER MACHINE

PARTS

- Ice Shaver Unit
- Foot Switch

OPTIONAL ITEMS

- Heavy Duty Extension Cord (10-12 Gauge / 50' or Less)
- Block(s) of Ice Broken into 2-3 inch pieces OR Ice Cubes
- Snowcone Syrup -Check with salesperson on availability and flavors
- Pump for Syrup
- Snowcone Cups (6 oz)
- Spoons
- Napkins

REQUIREMENTS

- 120 Volt / 7.5 Amps Power Source
- Level Table / Surface

CLEAN-UP

- Turn off Power
- Unplug unit from the power source.
- Remove any remaining ice.
- Wipe away any water.



Sample Photo / Actual Ice Shaver Style May Vary.

OPERATION INSTRUCTIONS

- 1. Allow ice soften 1 hour. Using ice straight from the freezer affects the quality of the shaved ice and can damage the shaver blade.
- Place Ice Shaver on a sturdy / level table.
- 3. Plug the unit into a power source.
- Lift cover lid and evenly load ice cubes into the hopper to within 1/2" of the top

- Close the lid and turn the Main power switch ON. Note: Machine will not operate unless cover lid is closed.
- Hold snow cone cup directly under the ice chute and press down on the foot switch. Release foot switch to stop ice shaving
- 7. To adjust the texture of the ice, use the blade adjustment knob.
- 8. Turn power switch off when machine is not in use

Ice Capacity

- 3.3 lbs of ice (in 2-3" pieces)
 - Estimate 1/3 1/2 pound of ice per cone

Parts	1
Optional Items	2
Requirements	3
Operation	4
Clean-Up	5
Ice Capacity	6
Helpful Hints	7
Locations	8

Volume # 2022-A Document Property of Diamond Event, Inc

HELPFUL HINTS

Do something special and consider adding the following items to your shaved ice to make them something special!

- Condensed Milk or Coconut Milk
- Fresh Fruits
- Chocolate Syrup
- Vanilla Ice Cream

Turning the adjustment blade clockwise will give you a finer texture, counter clockwise will give you a course texture

TROUBLE SHOOTING

• If you have any problems or concerns, please call your local Diamond Event Party Location.

LOCATIONS

SALT LAKE CITY 4518 South 500 West 801-262-2080