



POPCORN MACHINE

Parts	1
Optional Items	2
Requirements	3
Set-Up	4
Operation	5
Clean-Up	6
Popcorn Kits / Tips	7

Volume # 2013-B
Document Property of
Diamond Event ©

PARTS

- Popcorn Machine with the following:
1 Kettle w/Handle
3 Switches
 Light Switch
 Motor Switch
 Heat Switch
- Popcorn Scoop

OPTIONAL ITEMS

- 3 Prong Heavy Duty Extension Cord (10-12 Gauge / 50' or Less)
- Popcorn Kit (Oil, Salt & Kernels)

REQUIREMENTS

- 120 Volt / 10 Amp Power Source

SET-UP

- Level Surface

CLEAN-UP

- When cooled, remove any remaining kernels from the kettle.
- Remove any remaining popped corn from the plexiglass cabinet.



Sample Photo / Actual Popcorn Machine Style May Vary.

POPCORN KITS / TIPS

- 8oz Packet
- 7 Servings or 5 Cups
- 150 Calories
- 10+ Kits Per Hour
- Popcorn best if popped in 3-5 batches

TROUBLE SHOOTING

- If you have any problems or concerns, please call your local Diamond Event Party Location.

OPERATION INSTRUCTIONS

1. Turn on all switches.
2. Allow kettle to heat 3-4 minutes (when cold).
3. Cut OIL packet along top edge and squeeze into kettle.
4. IMMEDIATELY AFTER OIL MELTS, cut corn packet along the top edge and add 3 kernels.
5. When they pop, pour the remaining popcorn & salt into kettle.
6. Close lid.
7. Empty kettle immediately after popping stops.
8. On the last batch, turn off kettle halfway through popping cycle to eliminate smoking.
9. Turn all switches off.

LOCATIONS

SALT LAKE CITY
4518 South 500 West
801-262-2080