



Supplies Needed	1
Options	2
Requirements	3
Operation	4
Strike Down	5
Capacity	6
Tips	7

# VOYAGER SOUND SYSTEM

Volume # 2013-A  
Document Property of  
Diamond Event & Tent ©

## SUPPLIES

- Speaker with Amplifier & Controls
- Power Cord
- One Hand Held Microphone
- XLR Mic Cable - 20'

## OPTIONS

- Speaker Stand
- MP3 Cable
- Wireless Microphone Kit (Handheld or Lapel)
- Heavy Duty Extension Cord - 50' or Less

## REQUIREMENTS

- Fully Charged Battery or 120 Volt / 5 Amp Power Source

## STRIKE DOWN

- Turn power off
- Unplug system
- Wrap up cables



Sample Photo / Actual Sound System Style May Vary.

## TIPS

- Place the system speakers in front of the person speaking to avoid feedback squelches.
- If using the battery and the LED flashes or does not light, the batteries must be charged. Plug unit into a 120 Volt power source to charge/use.

## CAPACITY

- 1 Mic (Cord or Kit)
- 250-375 People Inside
- 125-250 People Outside (Actual performance will vary by conditions.)

## LOCATIONS

SALT LAKE CITY  
4518 South 500 West  
801-262-2080

OREM  
1350 Sandhill Road  
801-222-9311

OGDEN  
1639 South 1900 West  
801-393-5353

## OPERATION INSTRUCTIONS

1. Set all Input Levels to the minimum and tone controls to their 12:00 position.
2. Plug the mic cable into the MIC 1 jack.
3. Turn power on (Red LED above the switch will light)
4. Slowly increase Level Controls of the active Input Jacks to the desired volume.
5. Adjust the Bass & Treble Controls for the desired sound quality.