



Parts	1
Optional Items	2
Requirements	3
Instructions	4
Clean-Up	5
Warnings	6
Trouble Shooting	7

BUBBLE MACHINE

Volume # 2013-A
Document Property of
Diamond Rental ©

- PARTS**
- Bubble Machine with power cord
 - Bubble Fluid Tray
 - Hanging Bracket

- OPTIONAL ITEMS**
- Heavy Duty Extension Cord - 50' or Less
 - Bubble Fluid
 - Fuse # F1AL250V

- REQUIREMENTS**
- 120 Volt / 1 Amp Power Source
 - Bubble Fluid
 - Flat / Level Surface

- CLEAN-UP**
- Turn off power switch
 - Unplug from the power source
 - Loosen the front screw and remove the bubble fluid tray
 - Rinse out fluid tray (fluid not removed will thicken over time)
 - Return tray and tighten the front screw.



Sample Photo / Actual Bubble Machine Style May Vary.

- WARNINGS**
- Not for use outdoors in windy conditions.
 - Not for use indoors on a hard surface.
 - When thousands of bubbles burst on a hard surface, they can produce a slick surface.
 - Burst bubbles can make carpet damp.

- TROUBLE SHOOTING**
- If you have any problems or concerns, please call your local Diamond Event Party Location.

LOCATIONS

SALT LAKE CITY
4518 South 500 West
801-262-2080

- OPERATION INSTRUCTIONS**
1. Loosen the front cover screw
 2. Lift the top to expose the bubble fluid tray inside.
 3. Remove and fill the tray with bubble fluid no more than 3/4 full or 24 oz.
 4. Replace the tray inside the housing.
 5. Close cover and tighten the screw.
 6. Place on a flat surface or use the hanging bracket to install.
 7. Plug unit into a proper power source.
 8. Turn the "On/Off" switch on as needed.
 9. Check the bubble fluid tray as needed to refill
- One 24 oz. tray of bubble fluid will last approximately 30 minutes of continual use.*
- SEE WARNINGS!**