

**Parties** · Tents · Events

_	-	
		_

 Place the system speakers in front of the person speaking to avoid feedback squelches.

Supplies Needed	1
Options	2
Requirements	3
Operation	4
Strike Down	5
Capacity	6
Tips	7

Volume # 2015-A Document Property of Diamond Rental ©

# SUPPLIES (13)

- Center Amplifier w/controls.
- Attached Left Speaker
- Attached Right Speaker
- Speaker Stands (2)
- · Speaker Stands Bag
- Power Cord
- Handheld Microphone
- Mic Cable 20'
- · Mic Transport Bag
- 16' Speaker Cables (2)
- MP3 Player Cable

Sample Photo / Actual Sound System Style May Vary.

### **OPTIONS**

- Heavy Duty Extension Cord - 50' or Less
- NO Wireless Mics are available for this unit.

#### **REQUIREMENTS**

 120 Volt / 5 Amp Power Source

#### LOCATIONS

SALT LAKE CITY 4518 South 500 West 801-262-2080

OREM 1350 Sandhill Road 801-222-9311

OGDEN 1639 South 1900 West 801-393-5353

## OPERATION INSTRUCTIONS

 Flip open the cabinet latches on the sides and detach speakers.

**FENDER 2-SPKR PLUG-IN KIT** 

- Separate speakers and install on stands.
- Open storage compartment door and remove 4-cables.
- Plug speaker cables into the front of each speaker.
- 5. Plug each speaker cable into the back of the amp unit.
- Plug left & right speaker cables into their speakers.
- Make sure the power switch on the back of the amp is turned off.
- 8. Plug the power cord into the cord socket on the back of unit.
- 9. Plug the power cord into a power outlet.
- 10.Plug the microphone cable into 1 of the 3 mono mic plugs.

- 11. Rotate the MASTER VOLUME knob and all other CHANNEL VOLUME knobs to the left.
- 12. Turn on any external equipment first.
- Then turn on the Passport system (Green LED Light should illuminate.)
- 14. Turn the MASTER VOLUME up to 1/4.
- Adjust CHANNEL VOL-UME knobs until their LED light is Green or Yellow. (NOT RED!)
- If still RED, push the PAD button to reduce the mic/item's volume by 20 decibels.
- 17. Use the Master Volume control to adjust the overall volume.
- 18. Adjust the TONE knob to the center. Listen and adjust as needed.
- 19. Basic set-up in complete!

#### SPEAKER STANDS

- 1. Release the larger / lower swivel clamps.
- 2. Spread three legs in the desired position and lock clamps.
- 3. Release upper / small swivel clamps.
- 4. Lift center mast pole to the desired height.
- 5. Lock the upper / small swivel clamps.
- 6. Insert the safety locking pin into the mast.
- 7. Set a speaker atop each speaker stand.
- 8. Reverse to take down.

#### **CAPACITY**

- · 3 Handheld Mics
- 250-375 People Inside
- 125-250 People Outside (Actual performance will vary by conditions.)

### STRIKE DOWN

- Turn power off
- Unplug system
- · Detach Speakers
- Wrap up cables
- Mic w/Cord in bag
- Speaker Stands in large transport bag.