



**Parties · Tents · Events**

## EXPLORER SOUND SYSTEM

### SUPPLIES

- One Speaker with Amplifier & Controls
- Power Cord
- One Hand Held Microphone
- Mic Cable - 20'
- MP3 Player Cable
- One Speaker Stand
- Soft Rolling Case

### OPTIONS

- Heavy Duty Extension Cord - 50' or Less

### REQUIREMENTS

- Fully Charged Battery or 120 Volt / 5 Amp Power Source

### SOUND QUALITY

- One Speaker provides MONO signal.
- No Stereo Sound available.

### STRIKE DOWN

- Turn power off
- Unplug system
- Wrap up cables
- Return to rolling transport case



*Sample Photo / Actual Sound System Style May Vary.*

## OPERATION INSTRUCTIONS

1. Set all Input Levels to the minimum level position.
2. Set all the tone controls (bass & treble) to their 12:00 positions.
3. Plug the mic cable into the mono single MIC 1 jack..
4. Turn power on (Red

LED above the switch will light)

5. Slowly increase Level Controls of the active Input Jacks to the desired volume.
6. Adjust the Bass & Treble Controls for the desired sound quality.

Supplies Needed	1
Options	2
Requirements	3
Operation	4
Strike Down	5
Capacity	6
Tips	7

**Volume # 2015-A**  
**Document Property of**  
**Diamond Rental ©**

### TIPS

- Place the system speaker in front of the person speaking to avoid feedback squelches.
- If using the battery and the LED flashes or does not light, the battery must be charged. Plug unit into a 120 Volt power source to charge/use.

### CAPACITY

- 1 Mic (Corded or Kit)
- 250-375 People Inside
- 125-250 People Outside (Actual performance will vary by conditions.)

### LOCATIONS

**SALT LAKE CITY**  
4518 South 500 West  
801-262-2080

**OREM**  
1350 Sandhill Road  
801-222-9311

**OGDEN**  
1639 South 1900 West  
801-393-5353